


FISHER & PAYKEL

**DATA SHEET**
**48" Professional Cooktop Backguard**






PLAN VIEW




PROFILE VIEW




FRONT VIEW




Model no:
**BGCV2-3048**
(refer page 2 for metric measurements)

| **Product Dimensions** | **in** |
|---|---|
| Ⓐ Overall height of backguard | 30" |
| Ⓑ Overall width of backguard | 47 7/8" |
| Ⓒ Overall depth of backguard and racks | 9 3/4" |
| Ⓓ Depth of backguard | 15/16" |
| Ⓔ Depth of racks | 8 13/16" |
| Ⓕ Width of racks | 45 3/8" |
| Ⓖ Distance from top of backguard to bottom of racks | 10 15/16" |
| Ⓗ Distance from bottom of backguard to bottom of racks | 19 1/16" |
| Ⓘ Distance from top of backguard to top of brackets | 5 7/8" |


INDICATES PRODUCT DATUM ----------


DATE: **24.04.2018**

IMPORTANT: Throughout this guide, dimensions may vary by ±2mm (1/16"). Read the installation guide for detailed information on installing the product. For full installation instructions and specifications visit fisherpaykel.com


FISHER & PAYKEL

**DATA SHEET**
**48" Professional Cooktop Backguard**





PLAN VIEW




PROFILE VIEW




FRONT VIEW




Model no:
**BGCV2-3048**
(refer page 1 for imperial measurements)

| **Product Dimensions** | **mm** |
|---|---|
| Ⓐ Overall height of backguard | 762 |
| Ⓑ Overall width of backguard | 1216 |
| Ⓒ Overall depth of backguard and racks | 248 |
| Ⓓ Depth of backguard | 23 |
| Ⓔ Depth of racks | 224 |
| Ⓕ Width of racks | 1153 |
| Ⓖ Distance from top of backguard to bottom of racks | 278 |
| Ⓗ Distance from bottom of backguard to bottom of racks | 484 |
| Ⓘ Distance from top of backguard to top of brackets | 150 |

INDICATES PRODUCT DATUM ----------

DATE: **24.04.2018**

IMPORTANT: Throughout this guide, dimensions may vary by ±2mm (1/16"). Read the installation guide for detailed information on installing the product. For full installation instructions and specifications visit fisherpaykel.com