



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

105361
Dining Table

REVISION 0: 05/26/2014
REVISION 1: 02/20/2020

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: 105361



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	TOP		1PC
B	LEG		4PCS
C	LEAF		1PC
D	APRON		2PCS


HARDWARE IDENTIFICATION

1	WRENCH (12.8mm - RBW)		1PC
2	ALLEN WRENCH (M4 x 110mm - BLK)		1PC
3	HEX BOLT (M8 x 60mm - SILVER)		8PCS
4	LOCK WASHER (5/16" - RBW)		8PCS
5	FLAT WASHER (5/16" - RBW)		8PCS
6	BOLT (M6 x 50mm - RBW)		4PCS


ITEM: **105361**
ASSEMBLY INSTRUCTIONS

STEP 1

ATTENTION :
REMOVE ALL SCREW AND SMALL LEG.




STEP 2




ITEM: **105361**
ASSEMBLY INSTRUCTIONS



STEP 3




STEP 4




ITEM: **105361**
ASSEMBLY INSTRUCTIONS




STEP 5



STEP 6
COMPLETE



ITEM: 105361



Note: Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

105362
Dining Side Chair

REVISION 0: 05/26/2014
REVISION 1: 08/19/2014
REVISION 2: 02/18/2016
REVISION 3: 11/13/2020

ITEM: 105362



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

AF BACKREST



1PC

BF UPPER LEG FRAME



1PC

CF LOWER LEG FRAME



1PC

DF WOOD CLEAT



1PC

EF SEAT CUSHION



1PC


HARDWARE IDENTIFICATION

1 ALLEN WRENCH
(M4 x 110MM - BLK)



1PC

2 LONG BOLT
(M6 x 60MM - RBW)



4PCS

3 MEDIUM BOLT
(M6 x 35MM - RBW)




4PCS

4 SHORT BOLT
(M6 x 25MM - RBW)



4PCS

5 BOLT
(M7 x 50MM - ZB)



1PC

6 LOCK WASHER
(1/4" - BLK)



8PCS

7 FLAT WASHER
(M6 X 13MM - RBW)



4PCS

8 WOOD PLUG
(Ø14.5 X 9MM)



4PCS


NOTE :

Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item. Quantities shown are for one chair.


ITEM: **105362**

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: **105362**

ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM: **105362**



ASSEMBLY INSTRUCTIONS




STEP 5



STEP 6
COMPLETE



ITEM: **105362**



Note: Dimension tolerance $\pm 5\%$