


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

102888 Counter Height Table

REVISION 0: 05/11/2010 REVISION 1: 09/11/2012 REVISION 2: 12/02/2019

PAGE 1 OF 4

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

			ı				
1	SIDE PANEL WITH EXTRA CLEAT		1PC	5	LEAF		1PC
2	SIDE PANEL		2PCS	6	LEG	-	4PCS
3	DOOR PANEL	•	1PC	7	TOP PANEL		1PC
4	тор 🧲		1PC	8	BOTTOM PANEL		1PC

HARDWARE IDENTIFICATION

Α	HEX NUT (Ø5/16" x 1/2" - RBW)		4PCS	F	FLAT HEAD SCREW (Ø3.5 x 9/16" - RBW)	()	4PCS
В	BOLT (Ø1/4" x 1-9/16" - RBW)	()	14PCS	G	DOOR HINGE (120mm - RBW)		1PC
С	LOCK WASHER (Ø5/16" - RBW)		18PCS	Н	ALLEN WRENCH (M4 x 59mm - RBW)		1PC
D	SMALL FLAT WASHER (Ø5/16" x 19mm - RBW)		14PCS	ı	WRENCH (M4 x 50mm - RBW)		1PC
E	BIG FLAT WASHER (Ø5/16" x 22mm - RBW)		4PCS				


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


COASTER

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3




STEP 4






ASSEMBLY INSTRUCTIONS STEP 5




STEP 6 COMPLETE









Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

102889 Counter Height Chair

REVISION 0: 05/11/2010 REVISION 1: 09/11/2012 REVISION 2: 12/02/2019



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

1	BACK FRAME		1PC	4L LEFT FRONT LEG	1PC
2	SEAT CUSHION WITH FRAME		1PC	4R RIGHT FRONT LEG	1PC
3L	LEFT SIDE STRETCHER	e C	1PC	5 FRONT STRETCHER	1PC
3R	RIGHT SIDE STRETCHER		1PC		

HARDWARE IDENTIFICATION

A	LONG BOLT (Ø1/4" x 3" - RBW)		4PCS	E	FLAT WASHER (Ø5/16" - RBW)		9PCS
В	MEDIUM BOLT (Ø1/4" x 2-3/8" - RBW)		4PCS	F	FLAT HEAD SCREW (Ø4 x 40mm - RBW)	(1)	6PCS
С	SHORT BOLT (Ø1/4" x 1-3/8" - RBW)	(1)	1PC	G	ALLEN WRENCH (M4 x 59mm - RBW)		1PC
D	LOCK WASHER (Ø5/16" - RBW)		9PCS				

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


COASTER

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3




STEP 4
COMPLETE



PAGE 3 OF 3





Note: Dimension tolerance ±5%