

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

202091F(B1&B2) Full Bed

REVISION 0 : 10/08/2018 REVISION 1 : 01/02/2019 REVISION 2 : 07/05/2019

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

Α	HEADBOARD PANEL		1PC	D FOOTBOARD		1PC				
В	RIGHT HEADBOARD LEG		1PC	E BED SLAT		4PCS				
С	LEFT HEADBOARD LEG		1PC	BED SLAT F SUPPORT WITH LEVELER		4PCS				
B2 (BOX 2)										
G	BED RAIL		2PCS	202091F(B1) D FROM BOX 1		1PC				
НВ	2020911F(B1) FROM BOX 1 HEADBOARD COMPLETE		1PC	FOOTBOARD						

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 202091F (B1)

1 BOLT (M6 x 35mm - BLK)	0	6PCS	4 ALLEN WRENCH (M4 x 60mm - BLK)	1PC
2 LOCK WASHER (1/4" - BLK)		6PCS	FLAT HEAD 5 SCREW (M4 x 32mm - RBW)	8PCS
FLAT WASHER 3 (1/4"ID x 13mm - BLK)		6PCS		


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



ASSEMBLY INSTRUCTIONS


STEP 1




BACK VIEW

Note: Please take note of the marking sticker (L & R) on the headboard legs.

STEP 2



STEP 3




PAGE 3 OF 4


COASTERFURNITURE.COM




ASSEMBLY INSTRUCTIONS STEP 4



STEP 5



STEP 6 COMPLETE






COASTERFURNITURE.COM

PAGE 4 OF 4



Inner Size: 54.50"W x 76.00"D



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

202094 *Mirror*

REVISION 0 : 11/26/2013 REVISION 1 : 09/07/2018 REVISION 2 : 01/02/2019 REVISION 3 : 07/05/2019

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A DRESSER FROM BOX ITEM # 202093



1PC

B MIRROR



1PC


C MIRROR SUPPORT (PACK WITH DRESSER)



2PCS

HARDWARE IDENTIFICATION

1 FLAT HEAD SCREW (M4 x 32mm - RBW)



10PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

COASTER

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2 Arrow mark must be in line COASTERFURNITURE.COM




ASSEMBLY INSTRUCTIONS STEP 3

COMPLETE









Note: Dimension tolerence ± 5%