


3979 Westside Sectional | Components & Configurations


Leather Furniture

Components


LAF = Left-Arm-Facing
RAF = Right-Arm-Facing




-33
LAF Corner Sofa




-34
RAF Corner Sofa




-37
LAF Sofa




-38
RAF Sofa




-27
LAF Loveseat




-28
RAF Loveseat




-29
Armless Loveseat




-23
Full Wedge




-231
Corner Chair




-19
Armless Chair




-255
LAF Angled Chaise




-265
RAF Angled Chaise




-25
LAF Chaise



-26
RAF Chaise



-17
LAF Chair



-18
RAF Chair

Scale 1/4"=1'


Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. - Rev. 6/22
FLX-FR3979-CC-PP

FLEXSTEEL®

3979 Westside Sectional | Components & Configurations

Leather Furniture

Sample Configurations



Scale 1/4"=1'

Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. - Rev. 6/22
FLX-FR3979-CC-PP

FLEXSTEEL®