

FLEXSTEEL®




W1029-840

UPHOLSTERED DINING CHAIR

IMPORTANT


Carefully remove all parts from the carton, and put them individually on a soft cloth to prevent damage to the parts.

We have taken great care in the design of this product and request that you carefully and accurately follow our assembly instructions to ensure proper set-up.




Part List


Assembly Instructions 1/3



A. Backrest
1 piece




B. Seat Cushion
1 piece




C. Front Leg
2 pieces


Hardware List




Small Bolt
Ø5/16"-18 UNC x 1-3/4"
3 pieces




Medium Bolt
Ø5/16"-18 UNC x 2-1/4"
4 pieces




Large Bolt
Ø5/16"-18 UNC x 3"
4 pieces



Spring Washer
Ø5/16" x 1.5mm
11 pieces



Flat Washer
Ø5/16" x Ø19mm x 1.5mm
11 pieces



Hex Key
5/32"
1 piece

FLEXSTEEL®

Assembly Instructions 2/3


IMPORTANT NOTES

- Do not tighten up all the screws until each part is properly assembled.
- Use a soft cloth between these parts and the floor.

STEP 1


Peel up the bottom fabric cover under the cushion seat to prepare assembly. (See Figure 1)

Figure 1




STEP 2

Place Seat Cushion (B) on a clean, smooth surface. Attach Front Legs (C) with the Medium Bolts, Spring Washers and Flat Washers. Use Allen Key to tighten the Medium Bolts. (See Figure 2)



STEP 3

Place Backrest (A) on a clean, smooth surface. Attach Seat Cushion (B) with the Large Bolts and Small Bolts, Spring Washers and Flat Washers. Use Allen Key to tighten the Large Bolts and Small Bolts. (See Figure 3)



FLEXSTEEL®

Assembly Instructions 3/3

IMPORTANT NOTES

- Do not tighten up all the screws until each part is properly assembled.
- Use a soft cloth between these parts and the floor.

STEP 4

Attach the fabric cover over the bottom of the seat. (See Figure 4)




Figure 4

STEP 5

Adjust the levelers on the Front Legs (C) until the furniture is leveled. (See Figure 5)




Figure 5

CARE INSTRUCTIONS

- Avoid the use of harsh chemicals or abrasive cleaning materials.
- Wipe the table clean with a soft, dry cloth after each use.
- Wipe up spills quickly with a soft, dry cloth.

Flexsteel Industries, Inc.

For Parts or Customer Service call

toll-free:

1-888-415-3979

Monday-Friday

8:00 a.m. -5:00 p.m.

(Central Time)

Email:

customersolutions@flexsteel.com

www.flexsteel.com