



AR REFRIGERATORS
SOLID OVERLAY DOORS




## Alfresco OVERLAY DOOR INSTALLATION INSTRUCTIONS


## **DOOR REMOVAL:**

1. Begin by removing the existing door from the unit.


This can be done by removing the (3) 10-32 screws from the top hinge (located either left or right of the unit).




- 2. Once the top hinge is removed, the entire door can be lifted out of the unit along with the top hinge.
- 3. The door is quite heavy, please use assistance if needed.
- 4. Remove the top hinge bushing (slides out) from the door's bushing support bracket.
- 5. Remove the self closing hinge assembly (2) 10-32 screws at the bottom of the door
- 6. Remove the bottom bushing from the door's support bracket.



7. Remove the magnetic gasket from the door carefully pulling it out of the door plastic gasket track.



- 8. Install the overlay door lock mechanism 510-1624 on the face of the overlay door. (If the door does not have a lock system, skip this step). Use the proper template for the lock location:
  - Template 100-3807 for AR-24 units or
  - Template 100-3822 for AR-28 units.



KIT HARDWARE


SHOWN

9. Install the door handles onto the face of the overlay door material.

If you are using the OPTIONAL Alfresco Overlay handle kit, use the proper pattern for the handle mounting location

 AR-24 units use handle kit 510-1622 and use Template 100-3807


 AR-28 units use handle kit 510-0921 and use Template 100-3822



If you are using your own handle or pull hardware, install it according to your existing guidelines to match other cabinets.

Follow the above mentioned templates as a general guide to drill the necessary holes for the specific hardware you will be using.


- 10. Turn over the stainless door so the inside face is on the top.
- 11. Install the stainless door by centering it over the overlay door from all sides.
- 12. Press firmly into place (with clamping tools if required) and fasten the stainless door onto the overlay with the provided (16) # 4 x 1-1/4 screws.



- 13. Install the top bushing into the overlay and into now concealed bushing bracket. (push in)
- 14. Install the bottom bushing into the overlay. (push in)
- 15. Reinstall the self locking hinge assembly (2 screws)

## **INSTALLATION:**

16. Finish by re-installing the magnetic gasket and re-installing the door on the AR refrigerator as shown in reverse of the steps 1,2 and 7. Verify the door alignment and adjust as necessary using the hinge screws at the top and bottom.



SUPERIOR EQUIPMENT SOLUTIONS 1085 BIXBY DRIVE CITY OF INDUSTRY, CA. 91745

CUSTOMER: SES


C:\SES PDM\REFRIGERATION\ALFRESCO\AR-24 REV B\

WEIGHT: TBD

DRAWING TITLE:

AR-24 SAMPLE WOOD PANEL - BY CUSTOMER

LETTER SHEET 1 OF 2



SUPERIOR EQUIPMENT SOLUTIONS 1085 BIXBY DRIVE CITY OF INDUSTRY, CA. 91745

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF SUPERIOR EQUIPMENT SOLUTIONS, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION FROM SUPERIOR EQUIPMENT SOLUTIONS, INC. IS PROHIBITED CUSTOMER: SES

FINISH: VARIOUS WEIGHT: TBD


C:\SES\_PDM\REFRIGERATION\ALFRESCO\AR-24 REV B\

DRAWING TITLE:

AR-24 SAMPLE WOOD PANEL - BY CUSTOMER

LETTER

SHEET 2 OF 2



SUPERIOR EQUIPMENT SOLUTIONS 1085 BIXBY DRIVE CITY OF INDUSTRY, CA. 91745

CUSTOMER: SES


WEIGHT: APPROX 24.305 Lbs.

C:\SES\_PDM\REFRIGERATION\ALFRESCO\AR-24 REV B\

DRAWING TITLE: AR-24 OVERLAY DOOR ASSEMBLY PAGE SIZE:

LETTER

SHEET 1 OF 1





CUSTOMER: SES


C:\SES PDM\REFRIGERATION\ALFRESCO\AR-28\

FINISH: VARIOUS

WEIGHT: TBD

DRAWING TITLE: AR-28 SAMPLE WOOD PANEL - BY CUSTOMER LETTER

SHEET 1 OF 2





THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF SUPERIOR EQUIPMENT SOLUTIONS, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION FROM SUPERIOR EQUIPMENT SOLUTIONS, INC. IS PROHIBITED CUSTOMER: SES

C:\SES\_PDM\REFRIGERATION\ALFRESCO\AR-28\


**DRAWN BY: ADRIAN CRISCI** MATERIAL: SOLID WOOD PANEL FINISH: VARIOUS WEIGHT: TBD

LAST SAVED: 6/16/2025 1:21:39 PM PROJECT TITLE: AR-28

DRAWING TITLE:

PAGE SIZE: LETTER

SHEET 2 OF 2 AR-28 SAMPLE WOOD PANEL - BY CUSTOMER



Alfresco SUPERIOR EQUIPMENT SOLUTIONS 1085 BIXBY DRIVE CITY OF INDUSTRY, CA. 91745

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF SUPERIOR EQUIPMENT SOLUTIONS, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT WRITTEN PERMISSION FROM SUPERIOR EQUIPMENT SOLUTIONS, INC. IS PROHIBITED CUSTOMER: SES

🖫 C:\SES PDM\REFRIGERATION\ALFRESCO\AR-28\

**MATERIAL: VARIOUS** FINISH: N/A

WEIGHT: APPROX 29.078 Lbs.

PROJECT TITLE: AR-28 PAGE SIZE: DRAWING TITLE: LETTER SHEET 1 OF 1 AR-28 OVERLAY DOOR ASSEMBLY