

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

110311(B1&B2)
Dining Table

ITEM: 110311(B1&B2)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A	TOP		1PC
B	LEAF		1PC
C	LOWER CROSSBAR		1PC
D	UPPER CROSSBAR		1PC

B2 (BOX 2)

E	LEG FRAME		2PCS
---	-----------	--	------

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 110311(B1)


1	BOLT (Ø5/16 x 13 x 45mm - RBW)		16PCS
2	LOCK WASHER (Ø5/16 x 10 x 1.1mm - RBW)		16PCS
3	FLAT WASHER (Ø5/16 x 22 x 2mm - RBW)		16PCS
4	ALLEN WRENCH (4 x 60mm - RBW)		1PC

ITEM: 110311(B1&B2)




ASSEMBLY INSTRUCTIONS

STEP 1



BOTTOM VIEW

STEP 2




ITEM: **110311(B1&B2)**




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM: **110311(B1&B2)**





ASSEMBLY INSTRUCTIONS


STEP 5



STEP 6 COMPLETE




ITEM: **110311(B1&B2)**



Note: Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

110312
Dining Side Chair

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.









ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	BACK FRAME		1PC
B	SEAT CUSHION WITH FRAME		1PC
C	FRONT LEG		2PCS

HARDWARE IDENTIFICATION

1	LONG BOLT (Ø1/4x13x75mm - RBW)		4PCS
2	MEDIUM BOLT (Ø1/4x13x63mm - RBW)		4PCS
3	SHORT BOLT (Ø1/4x13x38mm - RBW)		2PCS
4	LOCK WASHER (Ø1/4x10x1.1mm - RBW)		10PCS
5	FLAT WASHER (Ø1/4x22x2mm - RBW)		10PCS
6	ALLEN WRENCH (4x60mm - RBW)		1PC


NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **110312**

ASSEMBLY INSTRUCTIONS
STEP 1



STEP 2




ITEM: **110312**




ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4

COMPLETE




ITEM: 110312



Note: Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

110313
Dining Arm Chair

ITEM:110313



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	SEAT AND BACK		1PC
B	LEFT BACK LEG		1PC
C	RIGHT BACK LEG		1PC
D	FRONT LEG		2PCS

HARDWARE IDENTIFICATION

1	BOLT (Ø1/4 x 13 x 63mm - RBW)		8PCS
2	LOCK WASHER (Ø1/4 x 10 x 1.1mm - RBW)		8PCS
3	FLAT WASHER (Ø1/4 x 2 x 22mm - RBW)		8PCS
4	ALLEN WRENCH (4 x 60mm - RBW)		1PC

NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **110313**




ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3 **COMPLETE**



ITEM: **110313**



Note: Dimension tolerance $\pm 5\%$